

---

Description Addendum PLEASE NOTE:

The COPY command copies the lines in reverse order  
If the copying process is halted due to insufficient  
memory space, any unoccupied lines will be at the  
beginning of the block.

## Commands

Lines 100 to 150 are copied to line 9000 and incremented by 5	>COPY 100-150,9000,5
Line 10 is copied to line 25	>COPY 10-10,25
Line 5 to last line are copied to 99 and incremented by 10 (Default).	>COPY 5-,99