
Procedure for hidden loaders.	
Loads program on disk 1	>CALL XB("DSK1.LOAD")
Break program.	PRESS FCTN 4 to break program.
Get address of interrupts.	>CALL ISROFF(I)
See if they are on.	>PRINT I
Save the programs to disk.	>CALL PSAVE(2,"DSK2.EXAMPLE1",
	3,"DSK2.EXAMPLE2")

Options

SAMS users will find this a easy way to save RXB SAMS support
EXAMPLE:

```
>100 Z$="DSK1.PAGE"  
>110 FOR L=15 TO 32 STEP 2  
>120 CALL SAMS(2,L,3,L+1)  
>130 CALL PSAVE(2,Z$&STR$(L),3,Z$&STR$(L+1))  
>140 NEXT L
```

The above program would save RXB SAMS pages 16 to 33 into
8 program image files named PAGE15 to PAGE33 on disk 1.

See SAMS, ISROFF, ISRON, EXECUTE, and MOVES.